

Headrest adjustment (1):

To rise: Hold the headrest with both hands and lift it up to a suitable height.

To lower: Hold the headrest with both hands and pull it down to a suitable height.

Back height adjustment (2):

To rise: Turn left the handle to unlock, hold the bottom of the back with both hands and lift it up to a suitable height, turn right the handle to lock.

To lower: Turn left the handle to unlock, hold the bottom of the back with both hands and lower it down to a suitable height, turn right the handle to lock.

Lumbar support adjustment (3):

To rise or lower the height:

Hold the lumbar support with both hands, lift it up or pull it down to a suitable height step by step.

To adjust the depth:

- To forward: Turn the handle upward to suitable position.

- To backward: Turn the handle downward to suitable position.

Armrest adjustment (4):

To rise up or lower down the armrest, pull up the button on the armrest and move up or down.

To move the arm top position, push the top forward or pull backward.


To move the arm top left and right position, push the top to leftside or rightside.

To adjust the arm width, turn anticlockwise the knob to unlock the arm, pull or push the arm to desired position, then turn clockwise the knob to lock.

Seat height adjustment:

To raise the seat height, remove weight from the seat and pull up on the height adjustment lever (5), release the lever when reaching the desired position.

To lower the seat height, while seated, pull up slowly on the height adjustment lever until the seat is at the desired height.



Seat and Backrest tilting adjustment (Tilt/Swing Lock):

To change seat and backrest's tilting position, pull up the adjustment lever (6) to unlock, then lie backwards the backrest to desired position, and push down the adjustment lever to lock.

To go back to the first position, pull up the adjustment lever, lie backwards again and then backrest will return automatically.

Independent backrest angle adjustment:

To adjust the backrest angle, pull up the seat angle adjustment handle (7) to unlock and lie backwards to desired angle, then push down the handle to lock.

Seat angle adjustment:

To adjust the seat angle, turn the seat angle adjustment handle (8) anticlockwise to lift up the seat, or turn clockwise to lower down the seat angle.

Seat depth adjustment:

To enlarge the seat depth, pull out the slider lever (9) and move forward to desired position, then release the lever.

To go back to the first position, pull out the slider lever and remove body weight from the seat.

Tilt tension adjustment:

To adjust the seat tilt tension, pull out and turn the tension adjustment lever (10) on the mechanism to desired tension, turn clockwise or anticlockwise.

Anticlockwise to stronger and clockwise to weaker.