

Headrest adjustment:

To adjust the headrest height, lift up the headrest (①) to desired position.

To adjust the headrest angle, turn the headrest directly to desired angle.

Back height adjustment:

To change the back height (②), lift up the back by pulling up the button (②) at the bottom of the back, then adjust the back height up or down to proper position.

Armrest adjustment (③):

To adjust the armrest angle, hold and rotate the armrest to left or right.



To rise up or lower down the armrest, pull up button on the armrest, hold and move up or down.

To move the arm rest position, push the top forward or pull backward.

Seat height adjustment:

To raise the seat height, remove weight from the seat and pull up on the height adjustment lever (④), release the lever when reaching the desired position.

To lower the seat height, while seated, pull up slowly on the height adjustment lever until the seat is at the desired height.



Tilt tension adjustment:

To adjust the seat tilt tension, turn the tension adjustment lever (⑤) on the mechanism to desired tension, turn clockwise or anticlockwise. Clockwise to stronger and anticlockwise to weaker.

Seat depth adjustment:

To enlarge the seat depth, push down the slider lever (⑥) and move frontward to desired position, then release the lever. To go back to the first position, push down the slider lever again and remove body weight from the seat.

Backrest angle adjustment (Swing/Tilt Lock):

To change backrest's position, turn backward the adjustment lever (⑦) to unlock, then lie backwards the backrest to desired position, and turn frontward the adjustment lever to lock. To go back to the first position, turn backward the adjustment lever, lie backwards again and then backrest will return automatically.